

E207 - LAB

▷ types of particle accelerators and their working principle

- LWR
- Cyclotron
- Microtron
- Elektron
- Synchrotron

▷ typical components


- optical elements ; dipole, quad, sext., solenoids, corrector magnets

$$\frac{1}{R} = \frac{e}{p} \cdot B \quad k = \frac{e}{p} \frac{dB}{dx} \propto I, \quad f = \frac{1}{kL} \quad \alpha = \frac{e}{p} BL$$

$$X(s) + \left(\frac{1}{R} - k(s) \right) X''(s) = \frac{\Delta p}{p} \cdot \frac{1}{R}$$

$$Z(s) + k(s) Z''(s) = 0$$


- acceleration mechanism



- monitoring : fluorescent screen in beam pipe \rightarrow frame grabber camera

▷ characteristic variables

- beam emittance is the area of the phase space ellipse \rightarrow conserved
twiss parameters



α is a measure for correlation

envelope given by $E = \sqrt{\epsilon \beta}$ $\alpha = -\frac{\beta'(s)}{2}$ $r = \frac{1 + \alpha^2(s)}{\beta(s)}$

▷ Measurement methods for determination of the beam emittance

- basic principle: measure the beam width at position $\sigma_1 = \sigma_1(x_0, y_0, p_0)$

- quad. scan: determine $\sigma_1^2(k)$ obtain $\epsilon_x, \epsilon_y, \epsilon_p$ from quadratic fit

$$\hookrightarrow \det(B) = \beta \gamma - \alpha^2 = 1$$

\hookrightarrow determine beam waist and use transf. eq. of μ function

- multi-screen - method: measure width at multiple screens and solve

$$\begin{pmatrix} \sigma^2(x_0) \\ \sigma^2(x_1) \\ \vdots \end{pmatrix} = M \cdot \begin{pmatrix} \epsilon_x^2 \\ \epsilon_{x_0} \\ \epsilon_p^2 \end{pmatrix}$$

\hookrightarrow use $\det(B) = 1$ to get ϵ

▷ Beam based alignment:

- use corrector angle α_x and measure deviation Δx after quad

